

ADVR-2200M

***New Type Hybrid Analog/Digital Voltage Regulator,
built to substitute some Digital Regulators used with
Marathon* Generators With PMG.
Easy to Set-Up and Program***



Installation Manual

Mounting
Plate
included



1. SPECIFICATION

Sensing Input E1, E2, E3

Voltage 220 ~ 600VAC, 60Hz
 DIP Switch SW1, 2 Selectable
 175 ~ 280VAC @ 220VAC
 330 ~ 490VAC @ 380/480VAC
 500 ~ 660VAC @ 600VAC

Frequency Single or 3 phase Input
 DIP Switch SW3 Selectable

Power Input P1 & P2

Input

Voltage 30 ~ 260VAC, 60Hz
 Single phase

Output

Voltage 85VDC @ 110VAC input
 170VDC @ 220VAC input

Current Continuous 5A Max.
 Intermittent 10A for 60 sec

Voltage Regulation

< ± 0.5% (with 4% engine governing)

Voltage Build-up

Residual voltage at AVR terminal > 5 VAC @ 25Hz

Thermal Drift

0.45% per °C change in AVR ambient

External Volts Adjustment

5% with 500ohm 1 watt trimmer
 10% with 1000ohm 1 watt trimmer

Excitation Resistance

> 9 ohm

Max. Power Dissipation

12 watt

Current Compensation

1 or 5A > 0.2VA (DIP Switch SW3 Selectable)

(C1,C2)

Max. ±7% @ P.F ±0.7

Analogue Voltage Input

Un 0 ~ 15% @ 0 ~ 10VDC or 0 ~ ±5VDC

Frequency Knee Point

60Hz Factory setting is 57 Hz
 50Hz Factory setting is 47 Hz

Response Time

<1 Cycle

Dimensions

150mm L * 135mm W * 55.5mm H

Weight

470g ± 2%

2. FIGURE AND SIZE





Figure 1 Outline Drawing

ATTENTION

1. AVR can be mounted directly on the engine, genset, switchgear, control panel, or any position that will not affect operation. For dimension reference, see Figure 1.
2. All voltage readings are to be taken with an average-reading voltmeter Meggers and high-potential test equipment must not be used. Use of such equipment could damage the AVR.
3. Fuse Specification : 6.3A / 250V Slow Blow Type
4. Terminal : "Fast-On" terminals 6.35mm (1/4 inch).


DIP SW Programming

SW1



1.OFF 2.OFF	208 to 240V
1.OFF 2.ON	380 to 480V
1.ON 2.ON	600V

SW2



4.OFF 5.OFF	<90KW	<i>Generator Size</i>
4.ON 5.OFF	90-500KW	
4.ON 5.ON	>500 KW	

SW1 & SW2 Sets the Generators Sensing Voltage

	OFF	ON
1	1 PHASE	3 PHASE
2	60Hz	50Hz
3	O/E PROTECT ON	O/E PROTECT OFF
6	CT 1A	CT 5A

SW1 -Set Sensing for 1 Phase or 3 Phase

SW2 - Set Generator Frequency

SW3 - Set Over Excitation Protection ON or OFF

SW4 and SW5 - Sets Generator Size

SW6 - Sets Size of Droop CT


Adjustments

U/F Under Frequency Protection Adjustment When generator RPM falls below the knee point, the under frequency protection circuit will activate and the voltage and frequency begin to decrease in linear descend.
Select frequency 60 or 50Hz according to the generator in use.

DROOP Droop Adjustment
When paralleling, the AVR increase or decrease its voltage output, when phase current leads or lag the voltage. The increase and decrease range can be preset by the DROOP adjustment.

LED Indicator lights when the generator is U/F Under-Frequency and when the generator is in Over-Excitation protection.

TRIM Trim Adjustment
When terminal A1 and A2 are biased with a DC voltage (0~10V), the TRIM is then used to adjust the influence this DC has on the output voltage of the AVR. If the TRIM (POT) is adjusted fully counter-clockwise, any bias voltage will not cause any influence. On the contrary if the TRIM is adjusted fully clockwise, then any signal will produce a maximum 10% effect.




VOLT Voltage Adjustment
Generator rated output voltage adjustment. Must be in accordance with the DIP Switch SW1-1 & 2 voltage range setting

STAB Stability Adjustment
Correct stability adjustment must be conducted while the generator is operating without load. First adjust the STAB potentiometer (POT) clockwise until the voltage becomes unstable, and then slightly adjust it anti-clockwise (About 1/5 turn). When the voltage just reaches the critical point (Knee point) of stabilization, where the voltage is stable yet very close to becoming unstable.

DIP Adjustment
The DIP adjustment allows some control over the generator voltage dip when applying load. It is used, when the generator uses a turbo-charger that sometimes lags the load and briefly operates below the UFRO knee point, (LED ON). With the DIP pot set CCW, the generator voltage characteristics will follow the normal V/Hz line as the speed falls below normal. Turning the DIP potentiometer CW increases the V/Hz slope, providing a greater voltage dip and aiding engine recovery. The DIP potentiometer can be set at any position to suit any engine type.

Wiring Connections



Sensing Voltage can be set from 200 to 600 Volts Program SW 1 1&2 correctly.

For single phase sensing bridge E2 & E3 and move SW2-1 to OFF

ATTENTION

The AC voltages recorded by the AVR are average values.

External VR: 500 ohms 1 Watt gives 5% adjustment range

External VR: 1K ohms 1 Watt gives 10% adjustment range